


STEPS


(1) Hardware




(2) Printed Graphic Fabric Banner



STEP 01 Connect to make long poles according to labelings.



STEP 02 Connect long poles with corner poles according to labelings.




STEP 03 Slide fabric banner on frame from top and zip up at bottom.



STEPS


(1) Hardware




(2) Printed Graphic Fabric Banner




STEP 01 Connect to make long poles according to labelings.



STEP 02 Connect long poles with corner poles according to labelings.




STEP 03 Connect support poles onto frame.




STEPS

STEP 04 Slide fabric banner on frame from left and zip up at right.




(1) Hardware



(2) Printed Graphic Fabric Banner





STEP 01 Connect to make long poles according to labelings.






STEPS


STEP 02 Connect long poles with corner poles according to labelings.



STEP 03 Connect support poles onto column frame.




STEP 04 Slide fabric banner on frame from top and zip up at bottom.




STEPS

STEP 05 Connect support poles onto column frame and canopy.




(1) Hardware




(2) Graphic printing fabric banner



STEP 01 Connect to make long poles according to labelings.




STEP 02 Connect long poles with corner poles according to labelings.




STEPS

STEP 03 Connect support poles onto frame.




STEP 04 Slide fabric banner on frame from top and zip up at bottom.





Booth Set Assembly

(1) Base



(2) TV Mount & Screw



(3) 180° C-Shaped Clip




(4) Arm Clip



STEPS


STEP 01

Insert display stands onto feet by pressing their knobs.



STEP 02


Connect display stands with arm clips.



STEPS


STEP 03

Insert display stands onto feet by pressing their knobs.



STEP 04



Interconnect display stands with C-shaped clips.



STEPS


STEP 05

Insert pole into base, screw clamp with hex wrench, place MDF board onto pole & insert into clamp with screw.




STEP 06

Screw TV mount with hex wrench.



STEPS



20X20FT-BOOTH-07