


STEPS

(1) Hardware








(2) Printed Graphic Fabric Banner (Optional)








STEP 01

Connect to make long poles according to labelings.




STEP 02

Connect long poles with corner poles according to labelings.




STEPS

STEP 03 Slide fabric banner on frame from top and zip up at bottom.




(1) Hardware







(2) Printed Graphic Fabric Banner (Optional)


**STEP 01**

Connect to make long poles according to labelings.

**STEP 02**

Connect long poles with corner poles according to labelings.





★ One Tool (Hex Wrench) **STEPS****STEP 03** Install cross bars in position.**STEP 04** Slide fabric banner on frame from top and zip up at bottom.

(1) Hardware



(2) Printed Graphic Fabric Banner (Optional)

**STEP 01** Connect poles according to labelings.

STEPS

STEP 02

Slide fabric banner on frame from left and zip up at right.



Booth Set Assembly



(1) Support Pole




(2) LED Light & Clip & 90° C-Shaped Clip



(3) Shelf & Bracket





(4) TV Mount & Screw



STEP 01

Connect support poles onto display stand and header.



STEP 02


Interconnect display stands with C-shaped clips.



STEPS


STEP 03

Screw TV mount onto display stand & support brackets onto TV's back with hex wrench, hang TV onto mount & screw.




STEP 04

Screw brackets onto display stand with hex wrench, insert shelves into slots.



STEPS

STEP 05 Screw light clips at top of display stands, slide lights onto them and adjust their direction.



10X10FT-BOOTH-12